


Mineral Fibers that were used as heat insulators and are resistant to fire = **ASBESTOS**



Potential Sources of Asbestos which might exist in homes built between 1930-1950:

Boilers, Heaters & Oil/Coal Furnaces

- ① Pipe insulation
- ② Insulation around furnace ducts
- ③ Air duct lining and wall gaskets and lining
- ④ Artificial ashes and embers sold for use in gas-fired fireplaces

Interior/Exterior Surfaces

- ⑤ Deck undersheeting
- ⑥ Roof felt and siding shingles
- ⑦ Blown-in fill or batt insulation
- ⑧ Window putty

- ⑨ Vinyl asbestos sheets, tiles and undersheeting flooring
- ⑩ Sprayed on acoustical ceiling or tiles
- ⑪ Textured paint and patching compounds for walls and ceiling joints
- ⑫ Walls and floors around wood burning stoves using asbestos paper, millboard, or cement sheets

Appliances & Equipment

- ⑬ Water heater, range hood, clothes dryer, dishwasher, portable heater, refrigerator and freezer
- ⑭ Heat reflectors on wood stoves

- ⑮ Hot water and steam pipes
- ⑯ Hair dryers
- ⑰ Ironing board covers

Electrical Equipment

- ⑱ Lamp sockets
- ⑲ Outlet and switch boxes
- ⑳ Recessed lighting
- ㉑ Main panel and fuse box

Miscellaneous

- ㉒ Cat box aggregate of either sand or clay
- ㉓ Fireplace logs
- ㉔ Asbestos hot pads and gloves